


## Installing WIRES-X software to the PC

1. Close the WIRES-X software.  
If “Enable WIRES-X Auto Start.” was selected when installing the WIRES-X software, right-click the WIRES-X icon displayed on the Windows task bar, then select “Quit” not to reboot the software automatically.
2. Download and unzip the “wx1xxen.zip” file of the WIRES-X software.
3. Execute “Install.exe” file in the unzipped folder.  
The “WIRES-X Installer” window will appear.
4. Click [**WIRES-X Software Setup**].  
The “Welcome to the WIRES-X Setup Wizard” window will appear.
5. Click [**Next**].  
The “License” window will appear.



6. Put a check-mark in the “I accept the terms in the License Agreement” check box, then click [**Next**].  
The “Destination Folder” window will appear.
7. Confirm the destination where the WIRES-X software will install and click [**Next**].  
The “Ready to install WIRES-X” window will appear.



If you put a check-mark in the “Enable WIRES-X Auto Start.” check box, the WIRES-X software will run automatically when Windows starts. Even when the WIRES-X software is terminated for some reason, it will reboot automatically.

8. Click [**Install**].  
Software installation will start.  
When installation completes, the “Completed the WIRES-X Setup Wizard” window will appear.
9. Click [**Finish**].  
The “Completed the WIRES-X Setup Wizard” window will close.  
When WIRES-X software installation has been completed properly, the [**Wires-X**] icon will appear on the Windows desktop.
10. Click [**Close**] in the “WIRES-X installer” window.  
Installation of the WIRES-X software is complete.

